

20 30 40 50

# *TPS1100 Professional Series*



## *Application programs Field Manual 1*

*English*

*Version 2.1*

***Leica***  
Geosystems

# *The quick way to start with the TPS1100 Programs.*



For additional details on single TPS1100 application program functions refer to the Applications Reference Manual on the CD.



To use the equipment in the permitted manner, please refer to the detailed safety instructions in the User Manual.

© 2001 Leica Geosystems AG Heerbrugg, © All rights reserved.

How to use this manual	4
General functions	6
Orientation and Height Transfer	8
Resection	16
Tie Distance	24
Stakeout	30
Remote Height	46
Free Station	51
Reference Line	62
Hidden Point	76

## How to use this manual

This manual gives step by step instructions for the basic uses of the TPS1100 field programs and explains some advanced program features. It shall be used together with a TPS1100 instrument or the TPS1100 PC simulation.


The proposed sequence of operations will guide you from the start to the end of a program.

### Example

Sequence of operation to be done.




Start Free Station from the program menu.



The title bar allows you to check if you are in the right dialog.

Enter the station Id and the instrument height.



Functions pointed to with a finger are optional.

To define a list of the target points and the measurement sequence.

---

## ***Symbols used in the sequence of operation***



Press the fixed key PROG.



User input is necessary.



Press the function key F1 to activate the function ALL.



Repeat operation.

---

## ***Other Symbols***



Important information and tips.

---

## ***Structure of the Field Manual***

1. Introduction
2. Basic Procedure
3. Advanced Feature
4. Configuration
5. Program Flow

Each program is constructed with the same chapter structure. Each chapter answers questions:

What does the program do? What are its typical uses?

How do I start the program? How do I use it?

Which special functions can I use to optimize my field work?

How can I configure the program to my needs?


How can I navigate through the program? Where can I find a specific function?

## General functions

This chapter explains common functions that are used in almost all programs (see also Quick Start).

---

### Measurement options




---

#### ALL key



To measure a distance and record measurement data according to the active REC-mask.

---

#### DIST and REC combination



To measure and display a distance.



To record displayed distance and angles according to the active REC-mask.

---

#### CONT




To accept displayed distance and angles, and continue to the next dialog without recording.

---

## *Search Point Dialog*

This dialog allows you to:

- Import the coordinates of a point from a data job or,
- Enter the coordinates of a point manually.



---

### *Coordinates available in Data Job*



To import coordinates from data job and go to the next step **without** showing the point coordinates



To import coordinates from data job and go to the next step **after** showing the point coordinates

---

### *Coordinates NOT available in Data Job*



To enter coordinates manually.



To measure and record point coordinates. Not available in every program.

## *Orientation and Height Transfer*

---

### *Introduction*

This program can be used for the following purposes:

- To determine the orientation at the instrument station.
- To determine the station elevation.
- To determine simultaneously the orientation and the station elevation.

The orientation and the station elevation are calculated from measurements to as many as ten known points.

Orientation and Height Transfer is often used when more than one known point is available around the station. Measurements to additional known points allow a reliability control of the calculated orientation and station elevation.

---


### *Basic procedure*



Before starting Orientation and Height Transfer the station must first be set using one of the following system functions or programs:

- Station Setup
- Resection, or
- Free Station.





## 1. Orientation only

### **Known:**

*Target points coordinates:*

- East, North

### **Unknown:**

- Orientation

### **Measure at least...**

- Directions to 1 target point

## 2. Orientation and Height Transfer

### **Known:**

*Target points coordinates:*

- East, North, Elevation

### **Unknown:**

- Orientation, Station Elevation


### **Measure at least...**

- Distance and directions to 1 target point



Points with elevation only can be used for the determination of the station elevation.

Start Orientation from the program menu.



To define a list of the target points and the measurement sequence.



Enter Point Id and reflector height at the first target point.



To search and import point coordinates from data job.



To measure and record first target point. See chapter "Measurement options".



Repeat sequence "Target point entry and Measurement" for your next target points.



Motorized instruments will drive automatically to the target point.




To calculate the orientation and the station elevation.

## Results

The results dialog displays:

- the current station coordinates.
- the oriented horizontal direction
- the a-posteriori standard deviations of the orientation and of the station elevation.



To record the Orientation and Height Transfer results.



To set **orientation** only.



To set **station elevation** only.



To set both **orientation** and **station elevation**.



To measure additional target points.  
Returns to the Target Point dialog.


## Advanced feature: Result analysis

Call the result analysis for individual measurements from the results dialog.

12

**MORE**  
● **F5**

Error Flag	Possible values
NONE	Measurement OK
HZ	Horizontal angle error
DIST	Distance error
HT	Height difference error



To display the results of the next point.

To measure additional target points.

To delete the measurements to the displayed point.



Define the point status:

<b>ON/OFF</b>	Measurements used/not used in calculation.
<b>Ignore Elev.</b>	Elevation not used in calculation.

**RECLC**  
● **F1**


To recalculate with the new settings.

**ESC**  
●

To go back to the result dialogs without changes.

## Configuration

Call the configuration in the first application dialog.





<b>Hz Ori Acc</b>	A priori standard deviation of the orientation.
<b>Ht Acc TP</b>	A priori standard deviation of the elevation of the target points.
<b>Posn AccTP</b>	A priori standard deviation of the position (East and North coordinates) of the target points.




If the computed (a posteriori) standard deviations are within twice the values entered for the a priori standard deviations, the computed station coordinates and orientation will be accepted.

<b>User Disp</b>	Use the display mask defined by the user.
<b>Two Faces</b>	Single or two face measurement.
<b>Log File</b>	Creation of a logfile.
<b>Log FName</b>	User definable name for the logfile.
<b>Data Job</b>	Selection of the job containing the fix point coordinates.
<b>Meas. Job</b>	Selection of the job for recording measurements.



Configuration can only be accessed in this first dialog.

available after 1 Point measured



**STORE** ● **F3** To set Orientation and/or Height and leave program

**S.ORI** ● **F1** Station Point Number WI 11  
Orientation correction WI 25

**S.HT** ● **F2** Station coordinates WI 84-86  
Last used reflector Ht WI 87  
Instrument Height WI 88

**SHIFT** ● **ROBST** ● **F2** Option for adjustment with Least Square or robust methods.


**SHIFT** ● **QUIT** ● **F6** To quit the Program at any time.

**Introduction**

Resection is used for station setup on an unknown point. The station coordinates and the Hz-circle orientation at the station are calculated from measurements to two known points.

In building and construction sites, resection can be used where the establishment of a permanent station is not practical, or where a marker is likely to be destroyed.

For Stake out, data collection or cadastral survey, resection allows you to choose the instrument location with the best view of the working area.

**Basic procedure****Known:**

1st and 2nd target points:

- East, North
- Elevation (optional)

**Unknown:**

Station coordinates:

- Stn. East, Stn. North
- Stn. Elev. (optional).
- Orientation





Check the geometry of the target points in relation to the station point. Avoid very small or very large angles at the station.

---

## ***Start resection***

Start Resection from the program menu.



<b>MAIN MENU: PROGRAMS</b>		MC
<b>RESEC\ Station Data</b>		MC
Point Id :	ST1	
Inst.Ht. :	1.65 m	



Enter the station Id and the instrument height.



<b>RESEC\ Target Point</b>		MC
Point Id :	1001	
Refl.Ht. :	1.60 m	



Enter Point Id and reflector height at the first target point.



To search and import point coordinates form data job.

RESEC\ Measure		MC
Point Id :	1001	
Hz :	363.5754 g	
V :	99.5647 g	
Refl.Ht. :	1.60 m	
Slope Dist :	----- m	



To measure and record first target point. (see chapter for "Measurement options")

RESEC\ Target Point		MC
Point Id :	1002	
Refl.Ht. :	1.60 m	



Enter Point Id and reflector height at the 2nd target point.



To search and import point coordinates from data.

RESEC\ Measure		MC
Point Id :	1002	
Hz :	175.5768 g	



To measure and record 2nd target point, and to display the resection results.

RESEC\ Results (L.SQRS)		MC
Station Id :	ST1	
No. of Pts :	2	
Inst.Ht. :	1.65 m	
East :	5003.542 m	
North :	2356.703 m	
Elevation :	453.344 m	↑
SET	STORE	COMP



To record the resection results.




To set station coordinates and orientation, and close the program.

## ***Advanced Feature: Compare Results***

The comparison function compares the station coordinates and the orientation calculated by the program to the station coordinates and the orientation currently set in the instrument.

Call the comparison function from the results dialog.



The Delta values are the results of a subtraction, e.g.

$$\Delta\text{East} = \text{Calc.East} - \text{Fix East}$$



To return to the results dialog.

## Configuration

Call the configuration in the first application dialog.




<b>Hz Ori Acc</b>	A priori standard deviation of the orientation.
<b>Ht Acc TP</b>	A priori standard deviation of the elevation of the target points.
<b>Posn AccTP</b>	A priori standard deviation of the position (East and North coordinates) of the target points.




If the computed (a posteriori) standard deviations are within twice the values entered for the a priori standard deviations, the computed station coordinates and orientation will be accepted.

<b>User Disp</b>	Use the display mask defined by the user.
<b>Two Faces</b>	Single or two face measurement.
<b>Log File</b>	Creation of a logfile.
<b>Log FName</b>	User definable name for the logfile.
<b>Data Job</b>	Selection of the job containing the fix point coordinates.
<b>Meas. Job</b>	Selection of the job for recording measurements.

## Program Flow



Configuration can only be accessed in this first dialog.



Station Point Number WI 11  
 Orientation correction WI 25  
 Station coordinates WI 84-86  
 Last used reflector Ht WI 87  
 Instrument Height WI 88



To quit the Program at any time.

# Tie Distance

## Introduction

Tie Distance is used to calculate the distance and the azimuth of a segment defined by two points.

The polygon points can be directly measured, imported from coordinate data job, or entered manually.


Two modes are available for calculating tie distances: Polygon and Radial (see illustrations below).



### Before starting Tie Distance:

The station must be set up and oriented.

## Polygon Mode



### Known or Measured:


Polygon Points 1, 2, 3, 4

### Unknown:

Tie Distance and Azimuth (Az.)  
between Pt.1 - Pt.2, Pt.2 - Pt.3  
...



## Radial Mode



### Known or Measured:

Central Point: 1  
Radial Point: 2, 3, 4

### Unknown:

Tie Distance and Azimuth (Az.)  
from the central point to the  
radial points 2, 3, 4.

## Basic procedure



Start Tie Distance from the program menu.



## First two points



The procedure for the first tie distance is the same for both the polygon and radial modes.

Tie  
Distance



Enter point Id and reflector height of the first point.



To measure and record the first point. (see chapter for "Measurement options")




To import point coordinates from a data file.



Repeat sequence for the second point. This completes the first tie distance and displays the corresponding results dialog.

### *Results in Polygon Mode*



To switch between polygon and radial modes.




To record Tie Distance results.



To measure or import the next polygon point.

## Results in Radial Mode



To define a new center point.

To switch between polygon and radial modes.




To record Tie Distance results.



To measure or import the next polygon point.

## Configuration

Call the configuration in the first application dialog.



<b>User Disp</b>	Use the display mask defined by the user.
<b>Two Faces</b>	Single or two face measurement.
<b>Log File</b>	Creation of a logfile.
<b>Log FName</b>	User definable name for the logfile.
<b>Meas. Job</b>	Selection of the job for recording measurements.
<b>Data Job</b>	Selection of the job containing the fix point coordinates.



To quit the configuration.

## Program Flow



To quit the Program at any time.



Configuration can only be accessed in this first dialog.




Change to Radial Mode



Change to Polygon Mode




To store the results:  
W11,25,35,37,39,79



**Tie  
Distance**

## Introduction



Stakeout is used to place marks in the field at predetermined points.

Different stakeout modes are available: polar, orthogonal, auxiliary points, or grid coordinates. Depending on the active stakeout mode, the corresponding stakeout elements of the measured point are calculated in relation to the point to be staked.

Changing to a different stakeout mode is possible at anytime.

Coarse stakeout is an optional step for approximate positioning preceding the iterative stakeout process. It may be used to direct the rod person from the point that has just been staked to the next point.

The points to be staked can be defined in two ways:

- The coordinates of the point are known. In this case, the points may be in data or entered manually within the stakeout program.
- The azimuth and horizontal distance to the point are known.

## Basic procedure




### Before starting Stakeout:

The station must be set up and oriented.

## Stakeout point



Start Stakeout from the program menu.



Enter the point Id of the point to be staked.




To search and import point from the data.  
Continues to the next stakeout dialog.



Starts distance measurement if locked on and EDM-mode is TRK/  
RTRK.




To enter a point given the azimuth and the distance:

- Manually enter the **azimuth** and the **Horiz.Dist** from the station to the point to be staked.
- Confirming the entry with  continues to the next stakeout dialog.

**Stakeout**

## Coarse Stakeout

### Mode: Azimuth and Distance



The stakeout elements, azimuth and distance, are calculated from the instrument station to the point to be staked.

STAKE\ Azimuth and Distance		MC
Point Id :	12	↑
Azimuth :	30°03'23''	
H <sub>z</sub> :	15°43'02''	
Slope Dist :	35.60 m	
Horiz Dist :	34.97 m	
ΔHeight :	0.75 m	
STAKE		

Turn the instrument until **H<sub>z</sub>** and **Azimuth** values get closer.

**ΔHeight** is the height difference from the station to the point to be staked.



To continue to the main stakeout dialog.




Motorized instruments drive automatically to the direction of the point to be staked.



## Main stakeout dialog

### Mode: Polar Stakeout



The stakeout elements are calculated in relation to the baseline defined by the instrument station and the measured point.

STAKE\ Polar Stake Out		MC
Point Id :	12	↑
Refl. Ht. :	1.65 m	
ΔHz :	▶ 16°03'23''	
ΔDist :	▼ -1.23 m	
ΔHeight :	FILL 0.15 m	
Elevation :	159.90 m	
ALL   DIST   REC   CONT   POSIT		

**DIST** To measure a distance and calculate the stakeout elements  $\Delta Hz$ ,  $\Delta Dist$ , and  $\Delta Height$ .



$\Delta Height$  is the height difference between the measured point and the point to be staked. It is displayed in 3D stakeout mode only.



Repeat procedure until the required positioning accuracy is achieved.



**ALL** To measure and record the stakeout point.  
Continues to the Search Point dialog for the entry of the next point to be staked.

## ***Advanced Feature: Configuration of the stakeout method***



Call the dialog for the configuration of the stakeout method from any stakeout dialog.



<b>Coarse Mode</b>	Selection of the coarse stakeout mode (see chapter " <i>Advanced Feature: Coarse mode</i> ").
<b>Stake Mode</b>	Selection of the main stakeout mode. (see chapter " <i>Advanced Feature.: Stakeout mode</i> ").
<b>Auto Pos.</b> <ul style="list-style-type: none"><li>• OFF</li><li>• 2D or 3D</li></ul>	Selection of the mode for automatic positioning to the point to be staked (for motorized instruments only). No automatic positioning. 2-dimensional or 3-dimensional positioning.
<b>Ht Offset</b>	Height offset addet to the design elevations of the points to be staked. CUT and FILL values refer to the elevations modified by the offset.
<b>Graphics</b>	Select the graphic mode to be displayed in the main stakeout dialog (see chapter " <i>Advanced Feature: Graphic mode</i> ").

<b>Symbols</b>	Select the display mode of symbols in the stakeout dialog. The symbols may be used to guide the rod person to the point to be staked.
• From Sta. (▲▼)	Guidance of the rod person from the instrument station.
• To Sta. (▼▲)	Guidance at the rod, in relation to the instrument station (e.g. if working in RCS mode).

---

***Advanced Feature:  
Coarse Mode***


---

***Coarse Mode = None***

The coarse mode is switched off. After the entry of the point to be staked in the Search Point dialog, the main stakeout dialog will be accessed directly.

## Coarse Mode = Line Offset

The stakeout elements are calculated in relation to the baseline defined by the two last points staked out.



STAKE \ Line Offset		MC
Point Id	:	12
Azimuth	:	30°03'23''
H <sub>z</sub>	:	15°43'02''
Line	:	1.550 m
Offset	:	1.430 m
ΔHeight	:	0.982 m
STAKE		↑



**Line** and **Offset** values are displayed after two points have been staked out.

**ΔHeight** is the height difference from the last point staked.




To continue to the main stakeout dialog.



Motorized instruments drive automatically to the direction of the point to be staked.

## Coarse Mode = Orthogonal



The stakeout elements are calculated in relation to the baseline defined by the instrument station and the last point staked out.

STAKE \ Orthogonal	
Point Id	: 12
Azimuth	: 30° 03' 23''
H <sub>z</sub>	: 15° 43' 02''
ΔLength	: -1.550 m
ΔCross	: 1.430 m
ΔHeight	: 0.982 m

STAKE



**ΔLength** and **ΔCross** values are displayed after the first point have been staked out.

**ΔHeight** is the height difference from the last point staked.




To continue to the main stakeout dialog.



Motorized instruments drive automatically to the direction of the point to be staked.

## Advanced Feature: Main stakeout mode

**Stake Mode = Orthogonal Stake**



1100pr11

The stakeout elements are calculated in relation to the baseline defined by the instrument station and the measured point.

STAKE \ Orthogonal		MC
Point Id :	12	↑
RefL. Ht. :	1.65 m	
ΔCross :	▶ 1.430 m	
ΔLength :	▼ -1.550 m	
ΔHeight :	FILL 0.982 m	
Elevation :	0.750 m	
ALL   DIST   REC   CONT		POSIT



To measure a distance and calculate the stakeout elements **ΔCross** and **ΔLength**.



**ΔHeight** is the height difference between the measured point and the point to be staked. It is displayed in 3D stakeout mode only.




Repeat procedure until required positioning accuracy is achieved.



To measure and record stakeout point.  
Continues to the Search Point dialog for the entry of to the next point to be staked.

## Stake Mode = Auxiliary Point



In this mode, the stakeout elements for points that can not be sighted directly are calculated from measurements to two auxiliary points.

STAKE\ Auxiliary points	
Point Id :	12
Refl. Ht. :	1.65 m
Hz angle 1 :*	----- m
Dist. 1 :*	----- m
Hz angle 2 :	----- m
Dist. 2 :	----- m

ALL DIST REC CONT POSIT

The auxiliary point to be measured is marked with an asterisk (\*).



To measure a distance to the first auxiliary point and calculate the stakeout elements **Hz angle 1** and **Dist. 1**. The asterisks switches to the second auxiliary point to be measured.




To measure a distance to the second auxiliary point and calculate the stakeout elements **Hz angle 2** and **Dist. 2**.



To stake out the next point. Continues to the dialog for the entry of the stakeout point.

## Stake Mode = Grid Coordinates



The displacements along the grid coordinates axes are calculated from the measured point to the point to be staked.

40

STAKE\ Grid Coordinates	
Point Id :	12
Refl. Ht. :	1.65 m
ΔEast :	1.430 m
ΔNorth :	-1.550 m
ΔHeight : FILL	0.982 m
Elevation :	0.750 m

ALL DIST REC CONT POSIT



To measure a distance and calculate the stakeout elements  $\Delta$ East,  $\Delta$ North and  $\Delta$ Height.



$\Delta$ Height is the height difference between the measured point and the point to be staked. It is displayed in 3D stakeout mode only.



Repeat the procedure until the required positioning accuracy is achieved.



To measure and record the stakeout point. Continues to the Search Point dialog for the entry of to the next point to be staked.



---


***Advanced Feature:***  
***Graphic mode***

The following modes are available for displaying stakeout graphics in the stakeout dialog:

<b>OFF</b>	No graphics are displayed.
<b>From Station</b>	The graphics are oriented from the instrument station to the point to be staked. This mode is recommended for guiding the rod person from the station.
<b>To Station</b>	The graphics are oriented from the current reflector position to the station. This mode is recommended for stakeout in RCS mode.
<b>To North</b>	The graphics are oriented to the North. This mode is recommended for stakeout in RCS mode and in the grid coordinates mode.
<b>From North</b>	The graphics are oriented to the South. This mode is recommended for stakeout in RCS mode and in the grid coordinates mode.

**Graphic mode= from Station**  
**Stake mode = Polar Stake**

Illustration of the stakeout dialog in the polar stake mode after having measured a distance.



Symbols:

- ▲ Instrument station
- × Reflector position
- Point to be staked

- \* The scale gives an indication of the distance between the reflector position and the point to be staked.




The graphics is updated dynamically when turning the instrument towards the point to be staked.

## Configuration



Call the configuration in the first application dialog:





<b>3D Stake</b>	3-dimensional stakeout ☞ The height elements are displayed only if an elevation is available for the point to be staked.
<b>Log File</b>	Creation of a logfile.
<b>Log FName</b>	User definable name for the logfile.
<b>Data Job</b>	Selection of the job containing the fix point coordinates.
<b>Meas. Job</b>	Selection of the job for recording measurements.



To exit the configuration dialog.

## Program Flow






To quit the Program at any time.

## Remote Height

### Introduction

### Basic Procedure



Remote Height is used to determine the elevation of inaccessible points, e.g. on cables or building facades.

First, the distance to a base point situated vertically below (or above) the remote height point must be measured. Then aim to the remote height point.

The coordinates of the remote point are calculated from the distance measured to the base point and from the angles measured to the remote point.



#### Before starting Remote Height:

The station must be set up and oriented.

#### Known:

- Distance to the base point
- $H_z$  and  $V$  to the remote point

#### Unknown:

- Coordinates of remote point:  
Elevation, East, North



In practice, it is not possible to maintain an exact vertical alignment of base point and remote point. Depending on the needed accuracy, you can set the maximal displacement of the remote point to be tolerated (see chapter "Configuration").

---

### Measure Base Point

Start Remote Height from the program menu.



MAIN MENU: PROGRAMS	
REMHT\ Meas. Base Pt.	
Point Id :	102
Hz :	123°32'23''
V :	10°34'20''
Refl. Ht. :	1.60 m
Slope Dist :	---- m
Elev. Diff :	---- m
ALL DIST REC REMOT	



Enter point Id and reflector height at the base point.




To measure and record the base point. (See chapter "Measurement options").

Continues to the next dialog for remote point measurements.

**Remote  
Height**

## Measure Remote Point



### $\Delta Ht. Diff$ :

*Height Difference between base and remote point.*

Dialog for remote point measurement.

REMHT \ Meas. Remote Pt.		MC
Point Id :	103	
Hz :	123°32'23''	
V :	10°34'20''	
Slope Dist :	----- m	
$\Delta Ht. Diff.$ :	----- m	
East :	45300.654 m	
<b>BASE</b> <b>STORE</b> <b> </b> <b> </b>		

To define a new base point.



Enter the point Id of the remote point and aim to the remote point.



The angles and the coordinates of the remote point are updated dynamically.



To record the measurements to the remote point. Note that coordinates are recorded only if defined in the active REC-mask.




To quit the program.




## Configuration


Call the configuration in the first application dialog:



Hz.Pos.Tol:



<b>User Disp</b>	Use the display mask defined by user.
<b>Hz.Pos.Tol</b>	Tolerance for vertical alignment: enter the maximal horizontal distance to be tolerated between base point position and remote point position. ☞ A warning is displayed if the tolerance is exceeded.
<b>Rec ΔHt= REC in WI37</b>	To store the ΔHeight Difference between base point and remote point as record WI37.
<b>Meas. Job</b>	Selection of the job for recording measurements.
<b>Data Job</b>	Selection of the job containing the fix point coordinates.



Configuration can only be accessed in this first dialog.



To record measurements to the remote point.  
Depending on CONF-settings:  
Record additional measurement block with  $\Delta$ Ht Diff (WI 37)



To quit the Program at any time.

---

## Introduction



Free station is used for a station setup on an unknown point. The station coordinates and the Hz-circle orientation at the station are calculated from measurements for up to ten known points.

A combination of directions and distances or of directions only may be measured to the target points.


If bad target points are found in the Free Station results, they can be suppressed or remeasured. The Free Station can be immediately recalculated.

Free Station is mostly used when more than two known points are available around the station. Measurements to additional known points allow a reliability control of the calculated station coordinates and orientation.

In building and construction sites, Free Station can be used where the establishment of a permanent station is not practical, or where a marker is likely to be destroyed.

For Stake out, data collection or cadastral survey, Free Station allows you to choose the instrument location with the best view of the working area.

## Basic procedure



### Known:

Target point coordinates:

- East, North
- Elevation (optional)

### Unknown:

Station coordinates:

- Stn. East, Stn. North
- Stn. Elev. (optional).
- Orientation


### Measure at least...

Distance and directions to 2 target points  
or directions only to 3 target points




Points with elevation only can be used in Free Station.

Start Free Station from the program menu.



Enter the station Id and the instrument height.



To define a list of the target points and the measurement sequence.



Enter Point Id and reflector height at the first target point.



To search and import point coordinates from data job.

FreSt\ Measure		MC
Point Id :	1001	
Hz :	363.5754 g	
V :	99.5647 g	
Ref1.Ht. :	1.60 m	
Slope Dist :	----- m	
<b>ALL</b>   <b>DIST</b>   <b>REC</b>   <b>CONT</b>		



To measure and record first target point.  
See chapter "Measurement options".




FreSt\ Target Point		MC
Point Id :	1002	
Ref1.Ht. :	1.60 m	



Enter Point Id and reflector height at the 2nd target point.



To search and import point coordinates from data job.

FreSt\ Measure			
Point Id	:	1002	
Hz	:	175.5768 g	



To measure and record 2nd target point.



Repeat sequence for the next target points.

Note: from the third point on, motorized instruments will drive automatically to the target.



To calculate the station coordinates and the orientation.

You may calculate after having measured at least:

- Distance and angles to 2 target points or
- Angles to 3 target points

### ***Free Station results***

The results dialog displays:

- the station coordinates
- the oriented direction (Hz. Ori)
- the a-posteriori standard deviations of the station coordinates and orientation
- the local scale factor

FreSt\ Results (L.SQRS)		MC
Station Id :	ST1	
No. of Pts :	3	
Inst.Ht. :	1.65 m	
East :	5003.542 m	
North :	2356.703 m	
Elevation :	453.344 m	
SET		STORE MEAS MORE COMP



To record the free station results.



To set station coordinates and orientation, and close the program.



To measure additional target points. Returns to the Target Point dialog.




---

**Advanced Feature:**  
**Compare Results**

The comparison function compares the station coordinates and the orientation calculated by the program to the station coordinates and the orientation currently set in the instrument.

Call the comparison function from the results dialog.



The Delta values are the results of a subtraction, e.g.

$$\Delta\text{East} = \text{Calc.East} - \text{Fix East}$$




To return to the results dialog.

## Advanced Features: Result analysis



Error Flag	Possible values
NONE	Measurement OK
HZ	Horizontal angle error
DIST	Distance error
HT	Height difference error

Call the result analysis for individual measurements from the results dialog.



To display the results of the next point.

To measure additional target points.

To delete the measurements to the displayed point.



Define the point status:

<b>ON/OFF</b>	Measurements used/not used in calculation.
<b>Ignore Elev.</b>	Elevation not used in calculation.



To recalculate with the new settings.



To go back to the result dialogs without changes.

## Configuration



Call the configuration in the first application dialog.




<b>Hz Ori Acc</b>	A priori standard deviation of the orientation.
<b>Ht Acc TP</b>	A priori standard deviation of the elevation of the target points.
<b>Posn AccTP</b>	A priori standard deviation of the position (East and North coordinates) of the target points.



If the computed (a posteriori) standard deviations are within twice the values entered for the a priori standard deviations, the computed station coordinates and orientation will be accepted.


<b>User Disp</b>	Use the display mask defined by the user.
<b>Two Faces</b>	Single or two face measurement.
<b>Log File</b>	Creation of a logfile.
<b>Log FName</b>	User definable name for the logfile.
<b>Data Job</b>	Selection of the job containing the fix point coordinates.
<b>Meas. Job</b>	Selection of the job for recording measurements.



Configuration can only be accessed in this first dialog.



To start calculations. Available after 3 Points have been measured.



To set the Station and leave the program.



Option for adjustment with Least Square or robust methods.



Station Point Number WI 11  
 Orientation correction WI 25  
 Station coordinates WI 84-86  
 Last used reflector Ht WI 87  
 Instrument Height WI 88



To quit the Program at any time.

---

**Introduction**

This program is used to set out points along a reference line or reference arc, with various offsets to the left and right. Radial offsets can be applied to the arc and the reference line can be shifted with parallel offsets or even rotated anytime to match predefined setting out instructions.

The orthogonal setting out elements of the target points are calculated in relation to the defined reference line/arc.

In Building and Construction, Reference Line is the specialized program to set out building foundations (batter staking).

It may also be used for simple alignment types such as water and sewer line layout as well as roadlines and bridges.

It is very convenient for orthogonal set out thanks to various offset possibilities and because point coordinates do not need to be precalculated. Only the coordinates of the start and end points of the reference line/arc are needed.

Points with known offset values from the defined line or arc can easily be set out with the function Line & Offset.

---

### ***Basic procedure***



#### **Before starting Reference Line:**


The station must be set up and oriented.

A Baseline or -arc is defined in the first step. There are three methods to define a base: Line, Radius Arc, and 3-Point Arc. Start any of the methods from the Reference Line Menu.



Line of sight to the baseline points is not needed. They can be imported from a data file.

In the picture, the reference line is defined by a parallel offset to the right of the baseline.



**Known:**

- 1st BasePt

- 2nd BasePt

Parallel **Offset** between  
Reference line and Baseline.

**Unknown:**

$\Delta\text{Offset}$ ,  $\Delta\text{Line}$ :


Position of point to set out on  
the reference line.



## Arc methods

2

### Radius Arc



**Known:**

- 1st Base Pt
- 2nd Base Pt
- Radius


Offset

**Unknown:**

- $\Delta$ Offset,  $\Delta$ Arc:  
position of point to set  
out on reference arc.

3

### 3-Point Arc



**Known:**

- 1st Base Pt
- 2nd Base Pt
- 3rd Base Pt


Offset

**Unknown:**

- $\Delta$ Offset,  $\Delta$ Arc:  
position of point to set  
out on reference arc.

Reference  
Line

## Define Reference Line




*direction of the  
baseline*

*Offset +  
to the right of the  
baseline*

*Offset -  
to the left of the  
baseline*

*For Arc the radial offset is  
applied to each point.*

- 1 Start Baseline from the Ref Line Menu




Enter the first point of the baseline.



To search and import point from data job.



Repeat sequence for second point of baseline.  
And define the reference line parameters:




To set out points with known offsets.

To define new baseline.

<b>Offset = 0</b>	Reference line = Baseline
<b>Offset ≠ 0</b>	Reference line parallel to Baseline

## Setting Out elements



- ΔOffset** *Perpendicular offset*  
**ΔOffset+** *To the right of the reference line.*
- ΔLine** *Line offset from the 1st Ref. Point.*  
**ΔLine+** *In the line direction.*

**REFL**  
 ● **F1**

REFLN\	Ref Line Results		MC
Point Id :		3	
ΔOffset :	1.230	m	
ΔLine :	2.463	m	
ΔHt :	0.235	m	
Elevation :	100.500	m	
<b>ALL</b> <b>DIST</b> <b>REC</b> <b>DONE</b>			



Enter Point Id to be set out.

**DIST**  
 ● **F2**

To measure a distance and trigger the calculation of the setting out elements: ΔOffset, ΔLine and ΔHt.

<b>ΔHt:</b>	Height Offset in relation to the reference Elevation (Elevation of the 1st Base Point).
<b>Elevation:</b>	Elevation of the measured point.

**SHIFT**  
 ●

**ΔL P2**  
 ● **F4**

To display ΔLine from the second point.

**ALL**  
 ● **F1**

To measure and record setting out point. Point Id is incremented.

**DONE**  
 ● **F4**


To return to Define Reference Line dialog.

**SHIFT**  
 ●

**QUIT**  
 ● **F8**

To quit the Reference Line program.

## Linie and Offset



**L&O**  
● **F2**

REFLN\ Define Reference Line

REFLN\ Line & Offset

Enter Offsets from Ref. Line  
Point Id : 110  
Offset : 10.555 m  
Line : 23.454 m  
DesignElev : 100.500 m



Enter Point Id of point to be staked, as well as perpendicular offset and distance along line. Entering an elev. is optional.

**CONT**  
● **F1**

REFLN\ L&O Results

Point Id : 110  
Refl. Ht. : 1.300 m  
 $\Delta$  Offset :  $\blacktriangleleft$  -0.542 m  
 $\Delta$  Line :  $\blacktriangleup$  1.222 m  
 $\Delta$ Ht : :FIL 0.500 m  
Elev. : 100.000 m

**DIST**

**DIST**  
● **F2**

To measure a distance and calculate the stakeout elements  $\Delta$  Offset and  $\Delta$  Line.




$\Delta$  HT is the height difference between the measured and the design elevation.






Repeat procedure until required positioning accuracy is achieved.

---

**Advanced Feature:  
Configuration of the L&O  
method**

**ALL**  To measure and record point. Continues to the first L&O dialog to enter offsets for next point.

**CONT**  Returns to first L&O dialog to enter offsets without recording data.


**SHIFT**  **METHD**  Call up the dialog for the configuration of the L&O method from the set out dialog.

<b>Stake Mode</b>	Selection of the stakeout mode:
Ortho-Reference	Stakeout elements are calculated in relation to the reference line/arc.
Ortho-Station	Stakeout elements are calculated in relation to the line defined by station and reflector.
Polar	Stakeout elements are calculated in relation to the station and the measured point.
<b>Auto Pos.</b>	Mode for automatic positioning to the point:
OFF	No automatic positioning
2D or 3D	2-dimensional or 3-dimensional positioning
<b>Symbols</b>	Symbols can be used to guide the rod person to the point to be staked.
Orthogonal	ON: positive in direction of reference.
Polar	- From Station (↑↓): Guides rod from station - To Station (↓↑): Guides from the rod in relation to the instrument station (if working in RCS mode)

## Advanced Feature: Rotated Ref. Line

### Configuration:

Line /  $\alpha$  = ON



Dialog for the definition of a rotated Reference line:

REFLN\ Define Reference Line	
1st BasePt :	1
2nd BasePt :	2
Offset :	5.000 m
Line :	1.500 m
Angle $\alpha$ :	15°00'00''

CONT NEW-L



Enter the **Line** offset to define the starting point of the reference line (1st Ref. Point).

Enter the rotation **angle  $\alpha$** .

CONT  
F1

REFLN\ Ref Line Results	
Point Id :	3
$\Delta$ Offset :	1.230 m
$\Delta$ Line :	2.463 m
$\Delta$ Ht :	0.235 m
Elevation :	100.500 m

ALL DIST REC CONT

DIST  
F2

To measure a distance and trigger the calculation of the setting out elements in relation to the new reference line and its starting point.

**Advanced Feature:**  
**Constant reference**  
**elevation**


For the configuration **Ref.Elev. = 1st Base Point**, the reference elevation for the calculation of  $\Delta$ Height values is the elevation of the 1st base point.

You can modify the reference elevation by specifying a height offset (**Ht.Offset**) in the dialog for the definition of the reference line.

REFLN\ Define Reference Line

1st BasePt :	1
2nd BasePt :	2
Offset :	0.000 m
Line :	0.000 m
Angle $\alpha$ :	0°00'00''
Ht.Offset :	1.500 m

MC



**Configuration:**

*Ref. Elev. = 1st Base Point*

*Ht. Offset = ON*

**Setting out element:**

*$\Delta$ Ht along the vertical, in relation to the Reference elevation*


## Advanced: Height Offset

### Interpolated reference elevation

For the configuration **Ref.Elev. = Baseline**, the reference elevation for the calculation of  $\Delta Ht$  values is the elevation of the baseline at the reflector position.

You can modify the reference elevation by specifying a height offset (**Ht.Offset**) in the dialog for the definition of the reference line.

72



### Configuration:

*Ref. Elev. = Reference Line*

*Ht. Offset = ON*

### Setting out elements:

$\Delta Ht$  Along vertical

$\Delta Perp.Dist$  Perpendicular to the Ref. line

$\Delta Spat.Dist$  Line offset along the Ref. line

Results dialog with setting out elements:

REFLN\ Ref Line Results	
Point Id :	3
$\Delta Offset$ :	1.230 m
$\Delta Line$ :	2.463 m
$\Delta Ht$ :	0.235 m
$\Delta Perp.Dist$ :	100.500 m
$\Delta Spat.Dist$ :	


ALL | DIST | REC | CONT




## Configuration




Line /  $\alpha$  :




Call the configuration in the first application dialog.



### Parameters for the definition of the Reference line:

<b>Offset</b>	To define a parallel offset of the Reference Line in relation to the Baseline.
<b>Line /<math>\alpha</math></b>	To define a line offset for the starting point of the Reference Line and an angle between Reference Line and Baseline.
<b>Ht Offset</b>	To define a height offset of the Reference Line in relation to the reference elevation.
<b>Ref. Elev.</b>	To define the reference elevation for the calculation of the height offset.  In order to change the setting for Ref. Elev., the parameter <b>Line/<math>\alpha</math></b> must be turned <b>OFF</b> .
<ul style="list-style-type: none"><li>• Ref. Elev. = 1st Base Point</li><li>• Ref. Elev. = Baseline</li></ul>	<p>The reference elevation is the elevation of the first Base Point.</p> <p>The reference elevation is the elevation of the Baseline at the intersection point with the vertical through current reflector position.</p>

Reference  
Line




## Other parameters

<b>Edit Elev.</b>	
= ON	Edit or add elevation in the Ref Line and L&O Results dialogs. New elevation is stored.
= OFF	Elevation cannot be changed or added in Results.
<b>Rec Diff</b>	To record setting out elements in a measurement block.
= NONE	Record measurement block according to REC-Mask.
= O, O/L, O/L/H or O/S, O/S/P	Record additional values: O = $\Delta$ Offset, L = $\Delta$ Line/ $\Delta$ Arc, H = $\Delta$ Height S = $\Delta$ Spat.Dist, P = $\Delta$ Perp.Dist (available only if Ref. Elev. = Baseline)
<b>User Disp</b>	To display the user-defined display mask in measurement mode.
<b>Logfile</b>	To create a logfile.
<b>Log FName</b>	User definable name for the logfile.
<b>Meas. Job</b>	Selection of the job for recording measurements.
<b>Data Job</b>	Selection of the job containing the fix point coordinates.



To exit the configuration dialog.


## Program Flow



AL P2



Configuration access only in this first dialog.



To quit program anytime.

Reference Line

---

***Introduction***

The program allows measurements to a point that is not directly visible using a special hidden-point rod.

The data for the hidden point are calculated from measurements to the reflectors mounted on the rod with a known spacing and a known rod length. The rod may be held at any angle as long as it is stationary for all measurements.

“Measurements” are calculated as if the hidden point was observed directly. These “calculated measurements” can also be recorded.

Typical uses are:


Measurement of inverts, building corner details of measurement of points behind overhangs.

## Basic procedure



### Before starting Hidden Point:

The station must be set up and oriented.



### Known:

*Hidden Point Rod Parameters*

- Rod Length
- Spacing between center of reflectors


### Unknown:

*Coordinates of Hidden Point*




Set rod parameters in CONFIGURATION.

Measurement sequence:



Start Hidden Point from the program menu.



Enter Point Id at first reflector.



Hold rod stationary at any angle with tip on the hidden point. Measure the reflectors in the illustrated sequence.



To measure and record in the active Measure Job. See chapter "Measurement options".



Repeat for second and optional third reflectors.



Motorized instruments may automatically drive to the third reflector.

## Results

Once all reflectors have been measured the program will display the results of the hidden-point calculation. Using 3 reflectors, the mean values of the hidden point are displayed.

HDNPT\ Results	
Point Id :	9
H <sub>z</sub> :	120.8865 g
V :	63.6419 g
Slope Dist :	3.020 m
Ht. Diff. :	1.632 m
East :	102.406 m

NEW REC



Enter Point Id of hidden point.



To record hidden point data.





To measure to a new hidden point.




To quit the Hidden Point program.

Call the configuration in the first application dialog.



<b>User Disp</b>	Use the display mask defined by the user.
<b>Meas. Tol.</b>	Limit for the difference between the given and measured spacing of the reflectors.
<b>Reflector</b>	Selection of the hidden point rod reflector.
<b>Add.Const.</b>	Display of the reflector constant.  This value depends on the selected reflector.
<b>No.of Refl.</b>	Number of reflectors on the hidden point rod.
<b>Auto Pos.</b>	Automatically point to optional third reflector (motorized instruments only)






<b>Rod Length</b>	Distance from center of end prism to tip of the hidden point rod.
<b>Dist R1-R2</b>	Spacing between the centers of prisms R1 and R2.
<b>Dist R1-R3</b>	Spacing between the centers of prisms R1 and R3.
<b>Meas. Job</b>	Selection of the job for recording measurements.
<b>Data Job</b>	Selection of the job containing the fix point coordinates.



When configuration is completed.



You must configure the hidden-point rod the first time you use the program. For continued use, it is only necessary to use CONFIGURATION when you want to change one of the settings.



Configuration can only be accessed in this first dialog.



To quit the Program at any time.

*Leica Geosystems AG, Heerbrugg, Switzerland has been certified as being equipped with a quality system which meets the International Standards of Quality Management and Quality Systems (ISO standard 9001) and Environmental Management Systems (ISO standard 14001).*



*Total Quality Management -  
Our commitment to total customer  
satisfaction*

*Ask your local Leica Geosystems agent  
for more information about our TQM  
program.*

710513-2.1.0en

Printed in Switzerland - Copyright Leica  
Geosystems AG, Heerbrugg, Switzerland  
2001

Original text

***Leica***  
**Geosystems**

*Leica Geosystems AG  
CH-9435 Heerbrugg  
(Switzerland)*

*Phone +41 71 727 31 31*

*Fax +41 71 727 46 73*

*[www.leica-geosystems.com](http://www.leica-geosystems.com)*